

## General

- **TV** to list the upcoming episodes for the currently selected show on the EPG, 'Program Finder', 'Program Recording Priorities', 'Fix Scheduling Conflicts' or search results screens.
- **Go** to edit recording options from the EPG, 'Program Finder', 'Program Recording Priorities', or 'Fix Scheduling Conflicts' screens.

## Watch a Recording screen

- **1** for meaning of the icons
- **OK** or **Play** to watch a recording
- **Red button** to delete
- **Go** presents options for recorded shows such as Auto Expire or Stop Recording

## Watching TV or a recording

- **Up** and **Down** arrow keys change the channel.
- Type a number to enter a channel number or jump amount (HHMM format).
- **Play** or **Pause** to pause / play.
- **Back/Exit** quits.
- **Go** puts the On-screen Display up again. During playback, **Go** toggles between position and show description info. If a jump amount is entered, jump to that position.
- **Menu/i** brings up the electronic program guide -- see the EPG section.
- **Pictures** to jump back the configured number of minutes. (default is 10)
- **Radio** to jump ahead the configured number of minutes. (default is 10)
- **SkipForward** to skip to next commercial break marker
- **Replay/SkipBackward** to skip back to previous commercial break marker
- **#** to toggle close caption support
- **Vol-** to decrease volume
- **Vol+** to increase volume
- **Mute** to toggle mute
- **Left** or **Rewind** to rewind the configured number of seconds. (default is 5)
- **Right** or **Forward** to fast forward the configured number of seconds. (default is 30)
- **Left** or **Rewind** (if a jump amount is entered) to jump back that amount.
- **Right** or **Forward** (if a jump amount is entered) to jump ahead that amount.
- **Green** starts rewind mode as if stickykeys are selected.
- **Yellow** starts fast forward mode as if stickykeys are selected.

## In Pause

- **Left** or **Rewind** to rewind 1 frame
- **Green** to rewind 1 second
- **Right** or **Forward** to advance 1 frame
- **Yellow** to advance 1 second

## LiveTV Browse Mode

- **Left** or **Rewind**: browse program prior to current listed program.
- **Right** or **Forward**: browse program following current listed program.
- **Up**: browse program on channel above current listed channel/program.
- **Down**: browse program on channel below current listed channel/program.
- **0-9**: enter a channel number to browse.
- **OK**: change channel to channel of current listed program.
- **Record**: Toggle recording of current program (cycles through types)
- **Back/Exit**: Exit Browse mode.

## While watching a recording

- **OK** will set a bookmark at that point. Next time you start the recording, you will automatically jump forward to this point and clear the bookmark.
- **Red button** exits the current recording and displays the Delete menu for it.
- **Menu/i** enters/exits edit mode.

## Electronic Program Guide (EPG)

- Arrow keys are used to move the highlighted program point around.
- **9** and **3** move the channel list up or down a page.
- **7** and **1** move the highlight left or right by one day.
- **Green** and **Yellow** move the highlight left or right by one page.
- **Go** will bring up more information about a show, and allow you to schedule a recording. If you select 'Record this showing' while watching Live TV you can Instant Record a program.
- **OK** will allow you resolve conflicts or change overrides. If the program is not already scheduled to record, it will act like pressing **Go** instead.
- **Menu/i** when on a channel will change to that channel.
- **Back/Exit** exits without changing the channel.
- **Record** will change the current item from Recording/Not-Recording. Successive keypresses cycle through the scheduled recording type list.
- **Prev.Ch** will mark/unmark the current channel as a 'favorite'
- **Videos** or **4** will toggle the guide listing between all channels and and 'favorites'.

## Recording Edit Mode

- The **Left** or **Rewind** and **Right** or **Forward** keys move forward and backward.
- The **Up** and **Down** keys alter the amount of time you jump forward and backward. Increments are: nearest cutpoint, nearest video keyframe, 1 frame, 0.5 seconds, 1 second, 20 seconds, 1 minute, 5 minutes, and 10 minutes.
- The **Pictures** and **Radio** keys move forward and backward to the nearest cut point.
- The **Green** and **Yellow** keys move forward or backward by 10 times the normal jump amount.
- **OK** allows you to set or delete a cut point.
- **SkipForward** loads the commercial skip list (if one exists) into the cutlist.
- **Replay/SkipBackward** will clear all cut points in the cutlist.
- **Go** inverts the cutlist.

## Viewing Scheduled Recordings/Resolving Conflicts

- **1** to show all recordings.
- **2** to show only important recordings.
- **3** to show only recording/conflicting recordings.
- **Go** to edit recording options.
- **OK** to resolve conflict or override.

## MythMusic

- **Pause**: pause playback
- **Yellow**: next track
- **Green**: previous track
- **5**: blank screen
- **6**: cycle visualizer mode
- **8**: refresh music tree
- **7** or **9**: decrease / increase track rating
- *How do I create a new playlist?* Using the MythMusic 'Select Music' menu option, setup the playlist as you normally would by adding songs or other playlists as needed. When you are ready to save the new playlist, highlight 'Active Play Queue' at the bottom of the selection tree and hit the **Go** key. This will pop up a menu allowing you to name and save the new playlist. You can also hit **OK** to bring up the popup on the Active Play Queue. This does not work on the playlists above, as **OK** is obviously bound to checking/unchecking the boxes. Any number (i.e. keypad on remote) will also bring up the menu in both cases.
- *How do I edit a playlist?* Highlight the playlist in the selection tree and hit the **Go** key then select 'Move to Active Play Queue' in the popup. You can now modify the 'Active Play Queue' like normal, adding songs and playlists by selecting them from the song tree. When you are done, highlight the 'Active Play Queue' in the selection tree and hit the **Go** key then select 'Save Back to Playlist Tree'. And whatever you were editing as your Active Queue before you moved an existing playlist 'on top' of Active reappears. Think of Active has having a push on, pop off capability, but with a depth of only 1.
- *How do I delete a track from a playlist?* Highlight the item in the selection tree and hit the Red button.

- *How do I rearrange the songs in my playlist?* Highlight a song and hit the **Music** key, the song will now have pair of red arrows in front of it. Use the up and down arrow keys to move it around in the playlist. When you have it where you want it, hit the **Music** button again.
- *How do I delete a playlist?* Highlight the playlist in the selection tree and hit the **Go** key then select 'Delete this Playlist' from the popup.

## MythBrowser

- Define sites and groups in the Settings dialog first. This is also where you can adjust the zoom level of the fonts on the webpages; The Zoom Level is a percentage between 20 (smaller text) and 300 (larger text).
- press **OK** on a group and the browser will open all websites in that group in tabs
- **Left**: previous link
- **Right**: previous link
- **Up** or **Down**: scroll the page
- **Back/Exit**: exit
- **OK**: follow a link
- **Pause**: switch to next tab
- **Print Screen**: popup menu

## Accessing the MythTV system over the network

- <http://xx.xx.xx.xx/mythweb/> (note: currently only available on the home network, not from the public internet)
  - username: public
  - password: \*\*\*\*\*
- over Windows networking, SSH, SFTP, etc., host: xx.xx.xx.xx -- username/pwd: same as above. The paths to access the files are
  - /myth/video = video files for MythVideo
  - /myth/music = MP3 files
  - /myth/gallery = picture files
  - /myth/tv = recorded TV as (very large) files
  - /myth/pretty = more human-readable version of tv files